


AQUAJOE®

LIGHTWEIGHT KINK-RESISTANT **EXPANDABLE HOSE** + **QUICK CONNECT ADAPTERS**

Model AJEXH50/75/100-RM



If you have any questions or comments,
please call the Snow Joe® + Sun Joe® customer service
department at:

1-866-SNOWJOE (1-866-766-9563)

THIS IS NOT YOUR OLD-FASHIONED GARDEN HOSE!

STOP! PLEASE READ FIRST

THANKS FOR PURCHASING YOUR NEW LIGHTWEIGHT, EXPANDABLE HOSE FEATURING AMAZING GELASTEX TECHNOLOGY! TO MAKE SURE YOU GET THE MOST OUT OF IT, WE'VE PUT TOGETHER A FEW QUICK TIPS AND TRICKS TO HAVE YOU UP AND FLOWING IN NEXT TO NO TIME.

HAVE A PROBLEM? WE'RE HERE TO HELP!





1-866-766-9563

PLUS, SO THE GOOD TIMES JUST KEEP ON FLOWING, YOU'RE ALWAYS COVERED BY OUR

2 YEAR WARRANTY

PROTECT YOUR PURCHASE TODAY: REGISTER ONLINE AT SNOWJOE.COM TO ENJOY FULL PRODUCT SUPPORT.




USING THE QUICK CONNECT ADAPTERS



Because we like you SO much, we've given you 3 adapters to get you started! The adapters provide a simple, fast and easy way of connecting and disconnecting your favorite irrigation accessories in a flash!

1. First, insert the adapter into your choice of irrigation accessory, and **twist until tight** (Figs. A – B).
2. Connect hose end to adapter by firmly pressing the Quick Connector to the adapter until they lock together (Fig. C). To disconnect, pull down on the Quick Connector collar to release.



USING THE SPIGOT ADAPTER






1. Connect adapter to outdoor spigot (faucet), as shown. **Tighten securely** (Fig. D).
2. Connect hose end to spigot adapter by firmly pressing the Quick Connector to the spigot adapter until they lock together. To disconnect, pull down on the Quick Connector collar to release.

LET'S STAY CONNECTED

The locking collar mechanisms on your expandable hose are specially designed to work with the highly flexible GELASTEX material to maintain a leak-free seal, regardless of how much the material stretches or contracts.






If Your Fittings Are Loose

1. Simply reconnect the locking collar assembly and tighten securely, as shown (Figs. A – B – C).



If Your Fittings Are Completely Off

1. Put the hose collar on (Fig. D).
2. Put the hose fitting on; twist as needed for a secure fit (Fig. E).
3. Tighten the two pieces together securely (Figs. F – G – H).



⚠ DON'T FORGET!

- Do NOT leave the water turned ON with the hose under pressure when not in use.
- Always turn the water OFF and drain the water from the hose after each use.
- Do NOT leave the hose under pressure for extended periods.
- Do NOT leave the hose in the sun for long periods; after use, store in a shady place.
- Avoid crushing, cutting or damaging the hose with heavy objects, car wheels, lawn mowers, etc.



SNOW JOE® + SUN JOE® REFURBISHED GOODS WARRANTY

GENERAL CONDITIONS:

Snow Joe® + Sun Joe® operating under Snow Joe®, LLC warrants this refurbished product to the original purchaser for 90 days against defects in material or workmanship when used for normal residential purposes. If a replacement part or product is needed, it will be sent free of charge to the original purchaser except as noted below.

The duration of this warranty applies only if the product is put to personal use around the household. It is the owner's responsibility to correctly perform all maintenance and minor adjustments explained in the owner's manual.

HOW TO OBTAIN YOUR REPLACEMENT PART OR PRODUCT:

To obtain a replacement part or product, please visit snowjoe.com/help or email us at help@snowjoe.com for instructions. Please be sure to register your unit beforehand to speed up this process. Certain products may require a serial number, typically found on the decal affixed to the housing or guard of your product. All products require a valid proof of purchase.

EXCLUSIONS:

- Wearing parts like belts, augers, chains and tines are not covered under this warranty. Wearing parts can be purchased at snowjoe.com or by calling 1-866-SNOWJOE (1-866-766-9563).
- Batteries are covered in full for 90-days from the date of purchase.

Snow Joe® + Sun Joe® may from time to time change the design of its products. Nothing contained in this warranty shall be construed as obligating Snow Joe® + Sun Joe® to incorporate such design changes into previously manufactured products, nor shall such changes be construed as an admission that previous designs were defective.

This warranty is intended to cover product defects only. Snow Joe®, LLC is not liable for indirect, incidental or consequential damages in connection with the use or misuse of the Snow Joe® + Sun Joe® products covered by this warranty. This warranty does not cover any cost or expense incurred by the purchaser in providing substitute equipment or service during reasonable periods of malfunction or non-use of this product while waiting for a replacement part or unit under this warranty. Some states do not allow exclusions of incidental or consequential damages so the above exclusions may not apply in all states. This warranty may give you specific legal rights in your state.

HOW TO REACH US:

We're here to help Monday through Friday from 9AM to 7PM EST and Saturday and Sunday 9AM to 4PM. You can reach us at 1-866-SNOWJOE (1-866-766-9563), online at snowjoe.com, via email at help@snowjoe.com or tweet us @snowjoe.

EXPORTS:

Customers who have purchased Snow Joe® + Sun Joe® products exported from the United States and Canada should contact their Snow Joe® + Sun Joe® distributor (dealer) to obtain information applicable to your country, province or state. If for any reason, you are not satisfied with the distributor's service, or if you have difficulty obtaining warranty information, contact your Snow Joe® + Sun Joe® seller. If in the event your efforts are unsatisfactory, please reach out to us directly.

HAVE A PROBLEM? WE'RE HERE TO HELP!
1-866-766-9563



snowjoe.com