

# bliss<sup>®</sup>

hammocks

## COLLAPSIBLE BEACH CHAIR WITH STORAGE BAG

MODEL: BBC-353

**READ THIS BEFORE ASSEMBLING & USING THIS PRODUCT. KEEP INSTRUCTIONS FOR FUTURE REFERENCE.**

**NOTE:** The illustrations below are for reference only and your chair may appear differently than illustrated.

**WEIGHT CAPACITY:** 275 lbs

### OPENING

- Grasp the front of the seat and top of the backrest, and press backward on the top of the backrest until the safety hinges snap/lock (Fig. 1). **NOTE:** Safety hinges will snap/lock when chair is fully open.



### CLOSING

- Grasp the front of the seat and top of the back, and pull them together in a fast motion. This will unlock the hinges and the chair will collapse and close (Fig. 2).



If you have any questions or comments,  
please call the Bliss Hammocks<sup>®</sup> customer service department at:

**1-800-695-2626**