# 2-PERSON WEEKENDER ROPE HAMMOCK (55" W)

\*CAUTION\* If you are not familiar with construction, hardware or the use of tools, please use a qualified general contractor to install. Improper installation may cause injury.

Safety First: Before entering hammock, inspect your hammock, hardware, installation points and objects supporting your hammock for wear or weakness. Make sure there is no excessive rust or twisting in the hanging hardware. Proceed carefully and take your time getting into and out of your hammock. Any hammock may tip if your weight isn't centered. A hammock is not a playground swing or a trampoline. Excessive swinging and other rough play may result in falls and may wear out your hammock and hardware prematurely. Small children should not play unsupervised in your hammock.

#### HAMMOCK CARE AND MAINTENANCE:

To prevent mildew and increase the useful life of your hammock, store it in a dry location during seasons and time periods when it is not in use. Avoid keeping in direct sunlight and rain for long durations. Some fading may occur.

Cleaning: Your hammock is hand washable with cold water and a mild detergent or soap. Do not use harsh chemical cleaners or bleach. Rinse well and let it dry thoroughly before storing. Keep rope and loops away from fabric while cleaning.

Wood Finish: To extend the usable life of the wood spreader bars, we recommend you varnish or oil it regularly, at least once per year.

**Storage:** Make sure the hammock is completely dry before storing in a dry location.

## HANGING INSTRUCTIONS


Since most hammocks are hand crafted, you should measure the overall length of your hammock, in order to determine the best hanging option for use.

Hammock Stand – When trees and posts are not available, the simplest way to use your hammock is on a free standing hammock stand. The overall length of the stand should be about 2.0' longer than the overall size of your hammock. To check if your hammock fits on your stand, hang the hammock on the stand and adjust to fit according to the "hanging guidelines" section, and on the diagram above.

Tree mounting — Two hardwood trees with a minimum of 12 inches in diameter (at least 37.5" in circumference) and a minimum of 13-15 feet apart are needed. You can also set up 1 post mount if you only have 1 tree available (see "post mounting" to learn more about mounting posts). Appropriate hardware like 2 S hooks and chains, or tree straps and S hooks need to be used for support and attachment to trees. Chains and S-hooks are recommended but may not be necessary, if you are limited in space between the 2 mount points. \*\*\*IMPORTANT: WHEN USING EYE SCREWS, MAKE SURE TO TIGHTLY SCREW EACH EYE SCREW ALL THE WAY IN THE TREE\*\*\*\*

**Post mounting** — When only 1 tree or no trees are available, pressure treated posts can be substituted. The posts should have minimum dimensions of 4" x 4" x 96". These posts should be cemented a minimum of 2 feet into the ground (sandy or loose earth might require longer posts and deeper cementing). In order to properly hang your hammock, 13'-15' feet of space between the posts is the minimum requirement depending on the size of the hammock. Posts should periodically be checked for cracking and rotting.

Hanging Guidelines: If needed, two chains and two S-hooks have been provided to help you hang your hammock correctly (please note: some models may only need 2 S hooks without chains to attach). Attach the hammock to the S-hooks and the S-hooks to the chains. The chains should be attached to hanging points that are about 15 feet apart and about 5 feet off the ground (depending on the size of your hammock). The hammock needs to sag in the middle. \*Important\* If your hammock is too tight it will make the hammock unstable and will cause flipping. The middle of the hammock at its lowest point should be between 8" to 3' feet from the ground. With use, your hammock might stretch and may need further adjusting.



## PRODUCT WARRANTY

All Bliss Hammock products are guaranteed against manufacturing defects for 1 full year from the date of purchase. Damage caused by the environment, improper use, or improper care and maintenance is not covered \*Guarantee excludes clearance/closeout items, non-retail, private sales, and auction website sales.

#### **↑** CAUTION

Falling and Strangulation Hazard! Hammocks can be unstable. Be careful entering and exiting your hammock as injury may result. Children can become entangled in hammock strings. Do not leave children unattended in hammock.

