

Instructions for 10ft Hammock Stand

(12 Parts, Not Including Hardware)

CONTENTS*

*Not to scale

Hardware



Double-ended Hex Wrench • QTY = 1



Washer • QTY = 2



Z-Hook • QTY = 2



Hex Nut • QTY = 2

Parts


“U” Bracket • QTY = 2




“L” Bracket • QTY = 4



Frame Tube • QTY = 6



The Z-hooks should be inserted entirely through the top hole of the “U” Bracket. Use the Double-ended Hex Wrench to tighten the Washer & Hex Nut to the Z-Hook. Do not over tighten.



At the end of each Frame Tube has (2) Spring-Pins built-in their interior. Make sure you securely insert them into the eyelets of the parts: “U” Brackets & “L” Brackets. You should hear a ‘click’ sound and see the head of the Spring-Pin through the eyelets of those parts.

After assembling the stand, to check if they are secure: pull & push each part to make sure they are not loose or can separate. Once all parts are secure, you may install your hammock (sold separately).

CAUTION

If you are not familiar with hardware or the use of tools, please use a qualified general contractor to install. Improper installation may cause injury. Safety First: Before using the hammock stand, inspect all parts and hardware as well as installation points and objects supporting your hammock for wear or weakness. Be sure all parts are properly secure, including the hardware. The Z-hooks, Hex Nuts, & Washers should all be tight and secure. Make sure there is no excessive rust or twisting in any of the hardware and parts. The hammock stand is not a playground or toy. Rough play may result in falls and may wear out your hammock stand and hardware prematurely. Small children should not play unsupervised in your hammock stand. Carefully, follow the directions of your hammock stand & hammock (sold separately).