

bliss™

outdoors

POP-UP BEACH TENT

BHT-A39

Please read instructions carefully and keep for future reference.


⚠ WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS CANOPY FABRIC. This canopy is made with flame-resistant fabric which meets CPAI-84 specifications. IT IS NOT FIREPROOF. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the canopy fabric may render the flame-resistant properties ineffective.

PROTECT YOUR CHILDREN: DO NOT leave children unattended inside a canopy or in camp. DO NOT allow children to assemble a canopy.


Failure to follow these warnings could cause death, serious injury, or permanent disability to you or others.

SETTING UP TENT:

STEP 1



STEP 2




If you have any questions or comments, please call the Bliss Outdoors™ customer service department at:

1-800-695-2626


©2021 Bliss Outdoors™ is a Trademark of Snow Joe, LLC | Made in China

TAKING DOWN TENT:

STEP 1



STEP 2



STEP 3

