

bliss™ outdoors

XL COLLAPSIBLE BEACH WAGON


BHW-100

READ THIS BEFORE ASSEMBLING & USING THIS PRODUCT
WEIGHT CAPACITY: 175 LBS


WASHING INSTRUCTIONS: Surface wash with a damp cloth only.
Spot clean. Do not immerse in water. Dry immediately.

ASSEMBLY:


1. Remove carry bag and inner mat. (Fig. 1)




2. Undo velcro storage straps and open wagon by pushing both side in opposite directions.. (Fig. 2)




3. Ensure the floor of the interior is flat and place the floor mat inside wagon. (Fig. 3)



4. Extend wagon pull handle to desired length and enjoy! (Fig. 4)



5. To fold wagon back into carrying bag, reverse the steps 1-4. (Fig. 4)



If you have any questions or comments,
please call the Bliss Outdoors™ customer service department at:
1-800-695-2626