

# bliss<sup>®</sup>

## hammocks

### 26" GRAVITY FREE CHAIR

GFC-430

READ THIS BEFORE ASSEMBLING & USING THIS PRODUCT

**CHAIR INSTRUCTIONS:**

To unfold recliner, you may need to release the locking system, If you purchased a recliner with a canopy, the canopy should be snapped to the frame, on the back of the recliner. Note: some models may not have a canopy and/or a drink tray. Recliner pictured may differ from the model you purchased. The illustrations below are for reference only and your recliner may appear differently than illustrated.

**ATTENTION:** Remove the drink tray if applicable before folding your recliner. If the recliner is folded without doing so, the drink tray will break. Unlock the two locking mechanisms that are under the armrests before folding your recliner. If recliner is folded with out doing so, the locking mechanism will wear.

Make sure your recliner is completely unfolded before sitting in. Please careful reclining while sitting in it. Body shape and weight will affect the way this recliner operates. Be careful and proceed with caution. To reduce the risk of injury, DO NOT play on, stand, or jump on the recliner. The recliner is intended for sitting and reclining only.

<p>1.</p> <p><b>CAUTION</b> Pinch Points</p> <p>! Moving parts under armrest while reclining. Do not put your hands under armrest while in motion.</p>	<p>2.</p> <p>* To release the locking system, lift lever on both sides of the recliner.</p>	<p>3.</p>
<p>4.</p>	<p>5.</p>	<p>6.</p>
<p>7.</p>	<p>8.</p> <p>Before closing the recliner, make sure the locks are unlocked.</p>	<p>9.</p>

IF YOU PURCHASED A GRAVITY FREE RECLINER WITH A PILLOW, SEE BELOW FOR INSTALLATION INSTRUCTIONS. PLEASE NOTE THAT THE RECLINER, DRINK TRAY AND/OR PILLOW PICTURED BELOW MAY DIFFER IN STYLE AND/OR COLOR FROM WHAT YOU HAVE PURCHASED.

#### PILLOW INSTRUCTIONS:

1. Thread bungee cord through eyelid of pillow.  
**Note:** Bungee cord should be in a plastic bag within the plastic bag containing the pillow.



2. Make sure canopy is unsnapped and brought to front of chair. Bring pillow around the front.



3. Make sure the flat part of the pillow is resting above the snap holders and flat against the fabric of the chair. Thread other end of bungee cord through the pillow's eyelid.



If you have any questions or comments, please call the Bliss Hammocks® customer service department at:  
**1-800-695-2626**

©2022 Bliss Hammocks® is a registered trademark of Snow Joe, LLC | Made in China

**PLEASE NOTE THAT THE RECLINER AND DRINK TRAY PICTURED BELOW MAY DIFFER IN STYLE AND/OR COLOR FROM WHAT YOU HAVE PURCHASED.**

**⚠ ATTENTION:** Remove the drink tray before folding your recliner. If the recliner is folded without doing so, the drink will break. Do not put excess weight on the drink tray to help avoid damage to the drink tray.

#### DRINK TRAY INSTRUCTIONS:

1. With recliner opened, place drink tray on left side of recliner underneath armrest. (Fig. 1)



2. Tilt the wide opening of the drink tray up and attach it between the two meeting poles. (Fig. 2)



3. Start to slide drink tray down until it cannot be pushed down anymore. (Fig. 3)



4. Press firmly to ensure cup holder is securely in place.