

bliss[®]

hammocks

ROCKING CHAIR WITH CANOPY AND PILLOW

GFR-091

READ THIS BEFORE ASSEMBLING & USING THIS PRODUCT. KEEP INSTRUCTIONS FOR FUTURE REFERENCE.

NOTE: Chair pictured below may differ in color/style from the one purchased.

WEIGHT CAPACITY: 360 lbs

⚠CAUTION: Make sure the chair is opened and locked before sitting in the chair.

⚠CAUTION: Moving parts under armrest while opening the chair. Do not put hands under armrests while in motion. When closing the rocking chair, keep clear of the space underneath the armrest and between the armrest and rocking legs to help prevent injury. Rocking chair is intended for sitting and rocking only. Avoid standing playing, jumping, etc on the rocking chair to prevent injury.

OPENING:

1. Fully open the rocking chair. Carefully push the metal frame of the back of the rocking chair while pushing down on the armrest until you cannot push any further (Fig. 1).



2. The locking system is located on the right side of the rocking chair frame where the seat and the back of the chair meet. The latch consists of 2 parts; top and bottom. To lock the chair, pull the bottom latch and under the protruding knob; then pinch the top and bottom parts together until it is secure. Make sure it is securely locked before sitting in the chair. To unlock the latch, pull both top and bottom parts away from each other and protruding knob.



3. Canopy is snapped against the back of rocking chair. Unsnap the canopy and rotate it over the chair. Adjust as needed. (Fig. 3).




ATTACHING PILLOW:

1. Thread bungee cord through eyelid of pillow. Make sure canopy is unsnapped and brought to the front of the chair. Bring pillow around the front.



3. Fold the rocking chair by pulling the metal frame of the seat inwards with the metal frame of the back. It is fully closed when the rocking legs are flush against the rest of the rocking chair.



CLOSING:

1. Unlock the rocking chair.
2. Snap the canopy into the snap locks on the back. Make sure the canopy is flat against the back.
3. Fold the rocking chair by pulling the metal frame of the seat inwards with the metal frame of the back. It is fully closed when the rocking legs are flush against the rest of the rocking chair. .

If you have any questions or comments,
please call the Bliss Hammocks[®] customer service department at:

1-800-695-2626