

ELECTRIC BLOWER/VACUUM/MULCHER

12-AMP | 200 MPH (MAX) | 450 CFM

A Division of Snow Joe®, LLC

Model SBJ604E-RM

Form No. SJ-SBJ604E-RM-880E-V1

THANKS FOR YOUR PURCHASE OF A REMANUFACTURED PRODUCT.

To make sure you get the most out of your product, be sure to register online at

snowjoe.com

to enjoy full product support.

PASTE UPC LABEL HERE



ELECTRIC BLOWER/VACUUM/MULCHER

12-AMP | 200 MPH (MAX) | 450 CFM

A Division of Snow Joe®. LLC

Model SBJ604E-RM

Form No. SJ-SBJ604E-RM-880E-V1

IMPORTANT! Safety Instructions

All Operators Must Read These Instructions Before Use

Any electrical appliance can be dangerous if used incorrectly. Some of the safety precautions given in this manual apply generally to many appliances. Other warnings are specific to the use of this electric blower vac.

Failure to follow all warnings, and instructions may result in electric shock, fire or serious injury.

WARNING! This indicates a hazardous situation, which, if not avoided, could result in death or serious injury.

CAUTION! This indicates a hazardous situation, which, if not avoided, could result in minor or moderate injury.

DANGER! This indicates a hazardous situation, which, if not followed, will result in death or serious injury.

General Safety FOR HOUSEHOLD USE ONLY

Before using, be sure that everyone using this tool reads and understands all safety instructions and other information contained in this manual. Save this manual and review it frequently prior to using this tool and when instructing others on the proper operating procedures.

CAUTION! Wear appropriate hearing protection during use. After long periods of extended use, the noise generated from this appliance may cause hearing loss if your ears are not properly protected.

WARNING! When using electric yard tools, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following:

- Keep work area clean and well-lit Cluttered, dark areas invite accidents.
- Replacement parts When servicing this unit, use only identical replacement parts. Replace or repair damaged cords immediately.

- **3.** Disconnect the tool Disconnect the blower vac from the power supply when it is not in use, before servicing it, when changing accessories and when performing any other maintenance task.
- 4 Avoid dangerous environments Do not use the blower vac in rain, damp or wet locations. Do not operate the blower vac in gaseous or explosive atmospheres or use the blower vac to pick up flammable or combustible liquids. Motors in these tools normally spark, and the sparks might ignite fumes.
- **5.** Keep children, bystanders and pets away All spectators, including pets, should be kept a safe distance away from the work area.
- **6.** Use the right tool Do not use the tool for any job except that for which it is intended.
- Extension cords To prevent electric shock, use only with an extension cord suitable for outdoor use.
- 8. Do not abuse the cord Never carry the blower vac by the cord or yank the cord to disconnect it from the receptacle. Keep the cord away from heat, oil, and sharp edges.
- Avoid accidental starting Do not carry the blower vac with your finger on the switch. Make sure the switch is off before plugging in the unit.

⚠DANGER! Do not manually place objects into the vacuum tube while operating the unit as this can seriously damage the unit and/or harm the operator. Keep both hands on the handles while the power is on.

DO NOT ATTEMPT to remove material or hold material to be vacuumed when the blower vac is on. Make sure the blower vac is off when clearing jammed material from the vacuum tube. Do not pick up the blower vac by the tube or attempt to carry the unit by the tube.

CAUTION! Moving parts will continue to run for several seconds after turning off the machine.

- **10. Moving parts –** Keep hands and feet away from moving parts. Keep guards in place and in proper working order.
- **11.** Do not force the tool It will perform better with less likelihood of personal or mechanical injury if it is used at the rate for which it was designed.
- 12. Wear personal protective equipment When using this tool, wear safety glasses with side shields or goggles to provide necessary eye protection. Wear ear defenders to prevent hearing damage. Use a face or dust mask if the work environment is dusty.

- 13. Dress properly Do not wear loose clothing or jewelry as such articles can become caught in moving parts. Wear a protective covering to contain long hair. Wearing rubber gloves and substantial non-slip footwear is recommended when working outdoors.
- 14. Stay alert Watch what you are doing. Use common sense. Do not operate the blower vac when you are tired or under the influence of drugs, alcohol or other medication.
- 15. Store idle tool indoors When not in use, the blower vac should be stored indoors in a dry and high or locked-up place out of the reach of children.
- 16. Maintain the blower vac with care Keep the blower tube and the fan area clear and clean for optimal performance and to reduce the risk of injury. Inspect the extension cord periodically and immediately replace it if damaged. Keep the handles dry, clean and free from oil and grease. Follow the additional recommendations described in the maintenance section of this manual.

Personal Safety

- · Use extra care when cleaning on stairs.
- Keep firm footing and maintain good balance at all times.
 Do not overreach. Overreaching can result in loss of balance.
- Turn off all controls before unplugging the tool.
- Do not use the tool if the power switch does not turn it ON or OFF. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- Do not use the tool with a damaged plug. If the tool is not working as it should or has been dropped, damaged, left outdoors or dropped into water, return it to an authorized Snow Joe® + Sun Joe® dealer or contact the Snow Joe® + Sun Joe® customer service department at 1-866-SNOWJOE (1-866-766-9563).
- Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- Carefully inspect your appliance prior to use and follow all label and marking instructions.
- Keep the end of the blower tube away from your face and body.
- Always unplug this appliance before connecting or disconnecting the tubes.
- · Do not use for wet material.
- Keep all parts of your body away from any moving parts and all hot surfaces of the unit.
- Do not put any object into the tool's openings. Do not use the tool with any opening blocked; keep openings free of dust, lint, hair or any other object that may reduce air flow.
- Check the work area before each use. Remove all objects such as rocks, broken glass, nails, wire or string which can be thrown or become entangled in the machine.

- Service on the product must be performed by qualified repair personnel only. Service or maintenance performed by unqualified personnel could result in injury to the user or damage to the product.
- This blower vac is intended for residential use only.
 Commercial use of this product is prohibited and will void the manufacturer's warranty.
- Never run the unit without the proper equipment attached.
 Always ensure the blower tubes are properly installed.
- When operating the unit as a blower, never point the blower tube in the direction of people or pets or in the direction of windows. Use extra caution when blowing debris near solid objects, such as trees, automobiles and walls.
- Be sure to secure the unit when transporting it.
- Never douse or squirt the unit with water or any other liquid.
 Clean the unit after each use as described in the Care +
 Maintenance section.

Electrical Safety

- Ground fault circuit interrupter (GFCI) protection should be provided on the circuit(s) or outlet(s) to be used for this electric blower vac. Receptacles are available having built-in GFCI protection and may be used for this measure of safety.
- Make sure that the mains voltage matches that listed on the unit's rating label. Using the improper voltage can damage the motor and injure the user.
- 3. To prevent electric shock, use only with an extension cord suitable for outdoor use, such as SW-A, SOW-A, STW-A, STOW-A, SJW-A, SJTW-A, or SJTOW-A.
 - Before use, check that the extension cord is in good condition. When using an extension cord, make sure to use one heavy enough to carry the current to the product. For lengths up to 50 ft (15 m), a No. 14 AWG (or greater) extension cord must be be used. For lengths more than 50 ft (15 m) and up to 100 ft (30 m), a No. 12 AWG (or greater) extension cord must be used. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating.



WARNING



Electric shock may cause SEVERE INJURY or DEATH. Heed these warnings:

- Do not allow any part of the electric blower/vacuum/ mulcher to make contact with water while it is in operation. If the appliance becomes wet while turned off, wipe dry before starting.
- Use only a UL-, CSA-, or ETL-rated extension cord for outdoor, all-weather use.
- Do not use an extension cord over 100 ft (30 m).
- Do not touch the appliance or its plug with wet hands or while standing in water. Wearing rubber boots offers some protection.

EXTENSION CORD CHART


Extension Cord	Up to 50 ft	+50 ft - 100 ft
Length	(15 m)	(+15 m - 30 m)
Wire Gauge (A.W.G.):	14	12

4. To reduce the risk of electric shock, this appliance has a polarized plug (i.e. one blade is wider than the other). Use this appliance only with a polarized UL-, CSA- or ETL-listed extension cord recommended for outdoor, all-weather use, such as the Snow Joe® + Sun Joe® SJTW-A 14-gauge 50-foot extension cord with lighted end (Model PJEXT50-B). Visit snowjoe.com to purchase this extension cord online or, to order by phone, call 1-866-SNOWJOE (1-866-766-9563).

The appliance plug will fit into a polarized extension cord only one way. If the appliance plug does not fit fully into the extension cord, reverse the plug. If the plug still does not fit, obtain a correct polarized extension cord. A polarized extension cord will require the use of a polarized wall outlet. The extension cord plug will fit into the polarized wall outlet only one way. If the plug does not fit fully into the wall outlet, reverse the plug. If the plug still does not fit, contact a qualified electrician to install the proper wall outlet. Do not modify the appliance plug, extension cord receptacle or extension cord plug in any way.

5. To prevent the appliance cord from disconnecting from the extension cord during operation, make a knot with the two cords as shown in Table 1.

Table 1. Method of Securing Extension Cord



- 6. Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- 7. If the supply cord is damaged, it must be replaced by an electrician or a power tool repairer.
- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
- 9. Have your tool repaired by an electrician or a qualified service center. This power tool complies with relevant safety requirements. To avoid danger, electrical appliances must only be repaired by qualified personnel using original spare parts; otherwise this may result in considerable injury to the user.

Double-Insulated Appliances

In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be performed only by qualified service personnel at an authorized Snow Joe® + Sun Joe® dealer. Replacement parts for a double-insulated appliance must be identical to the parts they replace. A double-insulated appliance is marked with the words "Double Insulation" or "Double Insulated." The symbol \Box (square within a square) may also be marked on the appliance.



DOUBLE-INSULATED: GROUNDING NOT REQUIRED. WHEN SERVICING, USE ONLY IDENTICAL REPLACEMENT PARTS.

This electric blower vac is double-insulated, eliminating the need for a separate grounding system. Use only identical replacement parts. Read the instructions before servicing double-insulated appliances. Use this electric blower vac only as described in this manual.

Safety Symbols


The following table depicts and describes safety symbols that may appear on this product. Read, understand, and follow all instructions on the machine before attempting to assemble and operate.

Symbols	Descriptions	Symbols	Descriptions		
	READ THE OPERATOR'S MANUAL(S) – Read, understand and follow all instructions in the user manual(s) before attempting to assemble and operate.		Keep bystanders and children a safe distance away.		
<u></u>	SAFETY ALERT – Indicates a precaution, a warning or a danger.	111 N V 11 11 11 11 11 11 11 11 11 11 11 11 1	WARNING! Do not expose the unit to rain or wet conditions.		
	Beware of flying objects and debris.		Wear hearing protection. Wear eye protection. Wear breathing protection.		
	DANGER! Rotating blades pose a serious risk of injury. Keep hands and feet away from openings while the machine is running.	STOP	The rotating part will continuously run for several seconds after you turn off the machine.		
	Immediately remove the plug from the mains if the power cable is damaged, frayed or entangled. Always keep the power cable away from heat, oil and sharp edges.		WARNING! Turn the machine OFF and disconnect it from the power supply before inspecting, cleaning, changing accessories or conducting any other maintenance task.		
	DOUBLE INSULATION – When servicing, use only identical replacement parts.				

Know Your Electric 3-in-1 Blower/Vacuum/Mulcher

Read the owner's manual and safety instructions carefully before operating the electric blower vac. Compare the illustration below to the electric blower vac in order to become familiar with the location of the various controls and adjustments. Save this manual for future reference.

- 1. Main handle
- 2. Cord retainer
- 3. Appliance cord



Technical Data

Rated Voltage	120 V ~ 60 Hz	Mode Conversion	Blower/mulching vacuum
Power	12 Amp	Variable Speed Settings	6
Air Flow Speed (Maximum)	200 MPH	Bag Capacity	9.1 gal (40 l)
Air Volume (Maximum)	450 CFM	Impeller	Polypropylene
Mulch Reduction Ratio	10:1	Weight	12 lbs (5.5 kg)

Unpacking

Carton Contents

- · Electric blower/vacuum/mulcher
- · Lower tube
- · Upper tube
- Bolts (2)
- · Washers (2)
- · Screws (2)
- · Collection bag
- · Supporting shoulder strap
- · Manual with registration card
- **1.** Carefully remove the electric blower/vacuum/mulcher and check to see that all of the above items are supplied.
- 2. Inspect the product carefully to make sure no breakage or damage occurred during shipping. If you find damaged or missing parts, DO NOT return the unit to the store. Please call the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563).

NOTE: Do not discard the shipping carton and packaging material until you are ready to use the electric blower/ vacuum/mulcher. The packaging is made of recyclable materials. Properly dispose of these materials in accordance with local regulations.

IMPORTANT! The equipment and packaging material are not toys. Do not let children play with plastic bags, foils or small parts. These items can be swallowed and pose a suffocation risk!


Assembly

WARNING! To avoid serious personal injury, read and understand all safety instructions provided.


WARNING! Do not connect to power supply until assembly is complete. Failure to comply could result in accidental starting and possible serious personal injury.

WARNING! To prevent serious personal injury, make sure the switch is in the OFF (O) position, the unit is unplugged and the impeller has come to a complete stop before attaching or removing tubes.


1. Place the upper tube on the ground in an upright position. Place the lower tube over the upper tube and press firmly for a secure connection (Fig. 1).




2. Secure both tubes with 2 washers and 2 bolts on top and bottom (Fig. 2).




3. Insert the tube assembly into the air outlet, and secure with the 2 screws (Figs. 3 & 4).






4. To connect the collection bag to the machine, first fasten the collection bag strap to the strap hook on the tube assembly, and then attach the bag adaptor to the air outlet (Fig. 5).



5. Clip the shoulder support strap to the top of the blower, as shown (Fig. 6).




Operation


Starting + Stopping

WARNING! Before switching on the tool, ensure that it is not in contact with any object.

1. Secure the extension cord to the motor housing using the cord retainer located at the rear of the blower. Then plug the appliance cord into the extension cord (Fig. 7).



2. To start the unit, press the ON (I) side of the ON/OFF switch (Fig. 8).




3. To stop the tool, press the OFF (O) side of the ON/OFF switch (Fig. 8).

WARNING! After switching off the tool the motor continues to run for a few seconds.

Speed Control


This unit is equipped with six variable speed settings (1 to 6) (Fig. 9).

- Turn the speed selector switch to position "1" or "2" for LOW speeds.
- Turn the speed selector switch to position "3" or "4" for MEDIUM speeds.
- Turn the speed selector switch to position "5" or "6" for HIGH speeds.




Shoulder support strap


This unit is equipped with a adjustable shoulder support strap that can help secure the unit in operation (Fig. 10).



1. To adjust the length of the strap, push it from one end to form a loop above, and let out as needed (Fig. 11).




2. Then pull the strap from the other side to tighten (Fig. 12).



Blower Mode


 Ensure the tubes are assembled correctly before operating. Turn the blower/vac mode selector switch to BLOWING MODE. Turn unit on (Fig. 13).



- Hold the blower firmly with one hand on the main handle and the other hand on the front handle. Sweep from side to side with the lower tube several inches above the ground or floor.
- Slowly advance the unit, keeping the accumulated pile
 of debris in front of you. Most dry blowing operations are
 better suited to low speeds rather than high speeds. High
 speed blowing is best for moving heavier items like large
 debris or gravel.

Vacuum/Mulcher Mode


- Once you have blown the debris/leaves into a pile, you can convert to vacuum mode to collect the debris.
- Ensure the tubes are assembled correctly before operating. Turn the blower/vac mode selector switch to VACUUM MODE. Turn unit on (Fig. 14).



With a firm hold on the vac, tilt the mulcher tubes 2 – 4 in. (5 – 10 cm) from the ground and use a sweeping action to collect light debris. The debris will flow into the bag. Items such as small leaves and twigs will be mulched as they pass through the fan housing. For longer bag life and increased performance, empty the bag frequently.

WARNING! Switch off the tool and disconnect the plug, and wait until the impeller comes to a standstill before dumping the collection bag.

 Open the zipper of the collection bag and empty it completely (Fig. 15).



- · Compost material does not belong with domestic waste.
- Regularly empty collection bag (the vacuum capacity decreases considerably when the collection bag is full).

WARNING! Do not vacuum solid objects such as stones, broken glass, pieces of metal.

WARNING! Do not vacuum liquids.

WARNING! Do not vacuum large volumes of leaf material at one time thus avoiding clogging of the vacuuming opening and blocking of the mulcher impeller.

Note: The mulching intensity depends on the size of the leaf material and its residual moisture.

Operating Tips

WARNING! Use the blower/vacuum/mulcher only in daylight or good artificial light.

- When using the blower vac, plant your feet firmly on the ground and place one hand on the unit handle and the other hand on the front handle.
- Wear personal protective equipment during your work session. This includes boots, safety glasses/goggles, ear defenders, long pants and a long-sleeve shirt.
- When using the unit as mulcher, make sure the bag is properly installed and zipped closed.
- Make sure the blower tube is not directed at anybody or any loose debris before starting the unit.
- Verify that the unit is in good working condition. Make sure the tube (and/or bag) is in place and secure.
- · Use the shoulder strap when using the unit as a mulcher.
- Use the supporting wheels to easily guide the tube along the ground.
- Operate power equipment only at reasonable hours—not early in the morning or late at night when people might be disturbed. Comply with times listed in local ordinances.
 Typical recommendations are 9:00 am to 5:00 pm, Monday through Saturday.
- To reduce noise levels, limit the number of pieces of power equipment used at any one time and operate power blowers at the lowest possible speed setting necessary to do the job.
- · Use rakes and brooms to loosen debris before blowing.
- · In dusty conditions, slightly dampen surfaces.

Care + Maintenance

WARNING! Disconnect the extension cord before performing any maintenance task.

If the extension cord is plugged into the appliance, someone could accidentally turn on the unit while you are performing maintenance on it, which could result in serious personal injury.

Cleaning the Unit

- Use a small brush to clean the outside of the unit. Do not use strong detergents, household cleaners that contain aromatic oils (e.g. pine and lemon) or harsh solvents such as kerosene as these substances can damage the plastic housing or the handles. Wipe off any moisture with a soft, dry cloth.
- Empty the bag after each use to avoid deterioration and obstructing air flow, which will reduce the performance of the unit.
- Wear eye protection and a dust mask. Clean the bag as needed. Turn the bag inside out after initial emptying and vigorously shake out dust and debris.
- After removing the collection bag, ensure that any possible dirt residues are removed from the air outlet area.
- 5. Wash the bag once a year, or more often if needed. Follow the steps below:
 - i. Remove the bag.
 - ii. Turn the bag inside out.
 - iii. Hang it up.
 - iv. Hose it down thoroughly.
 - v. Leave it hanging to dry.
 - vi. Turn the bag right-side out and reinstall.

Clearing a Blocked Tube/Impeller

WARNING! To avoid serious personal injury, be sure the unit is OFF and unplugged before clearing the impeller.

WARNING! To avoid serious personal injury, always wear gloves to protect yourself from the impeller blades or other sharp objects.

During the vacuuming process, certain objects such as cloth, rope or large diameter sticks may obstruct the fan and block the motor. You will notice a power drop or intermittent operation when using the unit.

In the event an obstruction occurs and power is curtailed:

- **1.** Slide the ON/OFF switch down to the OFF (O) position until the unit comes to a complete stop.
- 2. Unplug the unit.
- 3. Remove the tubes and the bag.
- **4.** Using protective gloves, carefully remove the material blocking the tube or impeller. Inspect the blades to ensure

- no damage has occurred. Rotate the impeller blades by hand to ensure the blockage is completely cleared.
- 5. Reinstall the blower tube or vacuum/mulcher tubes and the bag.
- 6. Wait 3 minutes for the motor to cool.
- Plug the unit back into the power supply and turn the ON/ OFF switch to ON (I). The blower vac will resume normal operation.

Storage

- Examine the electric blower/vacuum/mulcher thoroughly for worn, loose or damaged parts. Should you need to repair or replace a part, contact an authorized Snow Joe® + Sun Joe® dealer or call the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563) for assistance.
- Examine the extension cord thoroughly for signs of excess wear or damage. If it is worn or damaged, replace it immediately.
- Disconnect the extension cord from the electric blower/ vacuum/mulcher before storing.
- Store the cord with the electric blower/vacuum/mulcher indoors in a clean, dry and locked location out of the reach of children and animals.

NOTE: Devices for retaining extension cords are commercially available should you wish to purchase one.

Service and Support

If your Sun Joe® SBJ604E-RM 3-in-1 electric blower/vacuum/mulcher requires service or maintenance, please call the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563).

Model and Serial Numbers

When contacting the company, reordering parts or arranging service from an authorized dealer, you will need to provide the model and serial numbers, which can be found on the decal located on the housing of the unit. Copy these numbers into the space provided below.

Record the following numbers from the new product:	hοι	sin	g or	har	ndle	of y	our/
Model #:							
S B J 6 0 4 E - R M							
Serial #:							
	1	1	1	1	- 1	1	1

Troubleshooting

Problem	Possible Cause	Remedy
The blower/ vacuum/mulcher fails to operate	 No power supply Plug not connected Extension cord damaged ON/OFF switch defective Worn carbon brushes Defective motor Blowing/vacuum tube not completely mounted 	 Check power supply (power cable, circuit breakers, fuses) Connect the plug Replace extension cord Contact the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563) Mount two-part blowing/vacuum tube
The blower/ vacuum/ mulcher operates intermittently	ON/OFF switch defective Internal wiring defective Impeller blocked by foreign object	Contact the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563) Remove blockage
No/low blowing power	Transfer lever in vacuuming mode	Set selector switch to blowing mode
No/low vacuuming power	Transfer lever switch in blowing mode Collection bag is full, dirty Vacuuming opening clogged or blocked by foreign object	Set transfer lever switch in vacuuming mode Empty/clean collection bag Remove blockage

Only a company specialist may be able to correct faults that cannot be rectified with the aid of this table. Please call the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563).

Optional Accessories

WARNING! ALWAYS use only authorized Snow Joe® + Sun Joe® replacement parts and accessories. NEVER use replacement parts or accessories that are not intended for use with this tool. Contact Snow Joe® + Sun Joe® if you are unsure whether it is safe to use a particular replacement part or accessory with your tool. The use of any other attachment or accessory can be dangerous and could cause injury or mechanical damage.

Accessories	ltem	Model
SUNJOE	Sun Joe® SBJ604E replacement bag	SBJ604E-BAG
2	Snow Joe [®] + Sun Joe [®] SJTW-A 14-gauge 50-foot extension cord with lighted end	PJEXT50-B

NOTE: Accessories are subject to change without any obligation on the part of Snow Joe® + Sun Joe® to provide notice of such changes. Accessories can be ordered online at snowjoe.com or via phone by contacting the Snow Joe® + Sun Joe® customer service center at 1-866-SNOWJOE (1-866-766-9563).



SNOW JOE® + SUN JOE® REFURBISHED GOODS WARRANTY

GENERAL CONDITIONS:

Snow Joe® + Sun Joe® operating under Snow Joe®, LLC warrants this refurbished product to the original purchaser for 90 days against defects in material or workmanship when used for normal residential purposes. If a replacement part or product is needed, it will be sent free of charge to the original purchaser except as noted below.

The duration of this warranty applies only if the product is put to personal use around the household. It is the owner's responsibility to correctly perform all maintenance and minor adjustments explained in the owner's manual.

HOW TO OBTAIN YOUR REPLACEMENT PART OR PRODUCT:

To obtain a replacement part or product, please visit snowjoe.com/help or email us at help@snowjoe.com for instructions. Please be sure to register your unit beforehand to speed up this process. Certain products may require a serial number, typically found on the decal affixed to the housing or guard of your product. All products require a valid proof of purchase.

EXCLUSIONS:

- Wearing parts like belts, augers, chains and tines are not covered under this warranty. Wearing parts can be purchased at snowjoe.com or by calling 1-866-SNOWJOE (1-866-766-9563).
- Batteries are covered in full for 90-days from the date of purchase.

Snow Joe® + Sun Joe® may from time to time change the design of its products. Nothing contained in this warranty shall be construed as obligating Snow Joe® + Sun Joe® to incorporate such design changes into previously manufactured products, nor shall such changes be construed as an admission that previous designs were defective.

This warranty is intended to cover product defects only. Snow Joe®, LLC is not liable for indirect, incidental or consequential damages in connection with the use or misuse of the Snow Joe® + Sun Joe® products covered by this warranty. This warranty does not cover any cost or expense incurred by the purchaser in providing substitute equipment or service during reasonable periods of malfunction or non-use of this product while waiting for a replacement part or unit under this warranty. Some states do not allow exclusions of incidental or consequential damages so the above exclusions may not apply in all states. This warranty may give you specific legal rights in your state.

HOW TO REACH US:

We're here to help Monday through Friday from 9AM to 6PM EST. You can reach us at 1-866-SNOWJOE (1-866-766-9563), online at snowjoe.com, via email at help@snowjoe.com or tweet us @snowjoe.

EXPORTS:

Customers who have purchased Snow Joe® + Sun Joe® products exported from the United States and Canada should contact their Snow Joe® + Sun Joe® distributor (dealer) to obtain information applicable to your country, province or state. If for any reason, you are not satisfied with the distributor's service, or if you have difficulty obtaining warranty information, contact your Snow Joe® + Sun Joe® seller. If in the event your efforts are unsatisfactory, please reach out to us directly.



snowjoe.com

⚠WARNING! This product or its power cord contains chemicals, including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling. For more information go to www.P65Warnings.ca.gov.

⚠WARNING! Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known [to the State of California] to cause cancer, birth defects, or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
 crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specifically designed to filter out microscopic particles. For more information go to www.P65Warnings.ca.gov.