

30" WIDE GRAVITY FREE RECLINER INSTRUCTIONS

To unfold recliner, you may need to release the locking system.

<p>1</p> <p>CAUTION Pinch Points</p>	<p>2</p> <p>To release the locking system, lift lever on both sides of the recliner</p>	<p>3</p>
<p>4</p>	<p>5</p> <p>CAUTION Pinch Points</p> <p>CAUTION MOVING PARTS UNDER ARMREST WHILE RECLINING. DO NOT PUT YOUR HANDS UNDER ARMREST WHILE IN MOTION.</p>	<p>6</p>
<p>7</p>	<p>FOLDING THE RECLINER</p> <p>Before folding your recliner, please make sure locks are in the unlock position before closing up chair.</p>	<p>A</p>
<p>B</p>	<p>C</p>	<p>D</p>

PILLOW INSTRUCTIONS

PLEASE NOTE: THE RECLINER AND/OR PILLOW PICTURED BELOW WILL DIFFER IN STYLE AND/OR COLOR FROM WHAT YOU HAVE PURCHASED.




1. Thread bungee cord* through eyelid of pillow.



2. Bring pillow around the front.




3. Make sure the pillow flaps go over the metal frame and the flat part of the pillow is resting flat against the fabric of the chair. Thread other end of bungee cord through the pillow's eyelid.




***NOTE: BUNGEE CORD SHOULD BE IN A PLASTIC BAG WITHIN THE PLASTIC BAG CONTAINING THE PILLOW**

LOCK TOOL INSTRUCTIONS


LOCK TOOL CONSISTS OF 2 PARTS:




HOW TO ADJUST LOCK TENSION, IF NEEDED:



1. Remove the plastic caps covering each nut of the recliner lock using the flat-head rod.



2. Insert the flat-head rod into the side hole of the hexagon tube. Hold it by the flat-head rod in order to tighten or loosen the recliner lock nut to the desired tension. Turn to right to tighten, left to loosen. The locks must not be loose in order for the recliner to lock properly.



3. Once the desired tension of the lock nut is reached, pop the plastic caps back in to cover the nuts. To lock the recliner, move the lever down. To unlock the recliner, move the lever up.

PLEASE NOTE: Lock lever should point away from you in the unlocked position before use.

CAUTION

Make sure your recliner is completely unfolded before sitting in. Please be careful reclining while sitting in it. Body shape and weight will affect the way this recliner operates. Be careful and proceed with caution. To reduce the risk of injury, do not play on, stand, or jump on the recliner. The recliner is intended for sitting and reclining only. Unlock the two locking mechanisms that are under the armrests before folding your recliner. If recliner is folded with out doing so, the locking mechanism will wear.